



**Control Panels
Intruder
Fire**


The Guard Supreme
6 Panic + 1 Int.
Pin # 010003



The Guard Deluxe 3 Zone
3 Panic + 1 Int.
Pin # 010002



The Guard Deluxe
1 Panic + 1 Int.
Pin # 010001



Fire Guard, FG - 04
Pin # 010013



Guard MC - 2
6 Panic + 1 Int.
Pin # 010005

Guard MC - 3
6 Panic + 1 Int. + 4 Fire
Pin # 010006



Guard MC
4 Panic + 2 Int.
Pin # 010004



Guard MN
4 Programmable Zone
Pin# 010010

Sensors & Accessories



PIR - 1
PIR Sensor
Pin # 030519



M3
Inertia Shock Sensor
Pin # 030508




The Guard NM
Pin # 010008



LD96
Sounder
Pin # 040503



BCC - 2
Automatic Flot cum
Boost Charger
Pin # 020002




BCC - 1
Constant Current
Charger
Pin # 020201



5150 - W
2 wire Shock Sensor
Pin # 030511



**Magnetic Switch
MSW - 1**
Pin # 030001



FSW - 1
Foot Switch
Pin # 030006




PSW - 1
Panic Switch
Pin # 030002

LD - 72
Sounder
Pin # 040502



Power Pack - 1
12V, 100mA, 4AH
Pin # 020003



BC - 4
Battery Charger
Pin # 020009



SMSW - 1
Shutter
Magnetic switch
Pin # 030005



LD - 1
Light Detector
Pin# 030007



SPK - 1
Extn. Speaker 40W
Pin # 040704



SPS - 1, 12V, 7AH
Self Powered
Sounder
Pin # 020005



MN - JB
Junction Box
Pin # 060011



GMC - 4
4 Zone Fire Alarm Card
Pin # 060013



Smoke Detector
Pin # 030112



RI - 1
Response Indicator
Pin # 040006



MCP - 1
Manual Call Point
Pin # 040618



EH - 1
Electronic Hooter
Pin # 040505

**CCTV
Surveillance
System**

